


Dual Monitor Desk Mount

Instruction Manual



SKU: STAND-V002E




Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-v002e

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST







www.vivo-us.com
Chat live with an agent!



309-278-5303

<u>M</u> WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



TIPOVER WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM TIPOVER. TO HELP PREVENT TIPOVER:


- NEVER ALLOW CHILDREN TO CLIMB, STAND, HANG, OR PLAY ON ANY PART OF MONITOR OR STAND.
- USE TIPOVER RESTRAINT OR ANCHOR STAND TO WALL

USE OF TIPOVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE RISK OF TIPOVER.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.




NOTE: SOME HARDWARE INCLUDED MAY NOT BE USED



ASSEMBLY STEPS


STEP 1



STEP 2

OPTION A: Clamp Installation


Slide cable management clip (H) and plastic cover (I) onto bottom of pole (A). Stick rubber pads (M) to bottom of clamp (B). Thread pole (A) onto clamp (B). Tighten grub screws in bottom of clamp (B) using 3mm allen wrench (O). Secure clamp (B) to desktop as shown in diagram.




STEP 2 (Continued)

OPTION B: Grommet Base Installation


Remove screw from top of bolt in clamp (B). Stick rubber pads (M) to bottom of grommet base (C). Slide cable management clip (H) and plastic cover (I) onto bottom of pole (A). Thread pole (A) onto grommet base (C). Tighten grub screws in bottom of grommet base (C) using 3mm allen wrench (O). Slide support plate (L) over bolt and slide through grommet hole in bottom of desktop. Thread into bottom of pole (A).




STEP 3




STEP 4




STEP 5




STEP 6







STEP 8



STEP 9



Adjust as Desired





Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

 \subseteq

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S